FUJITSU

SPARC® Enterprise M8000/M9000 Servers Getting Started Guide

Accessing the Documentation Files

The documentation set for SPARC® Enterprise M8000/M9000 servers is available on the following websites.

Global Site

`http://www.fujitsu.com/sparcenterprise/manual/`

North American Site

`https://download.computers.us.fujitsu.com/`

Japanese Site

`http://primeserver.fujitsu.com/sparcenterprise/manual/`

Note – For late-breaking information about the SPARC Enterprise M8000/M9000 servers hardware, software, or documentation, refer to the *SPARC Enterprise M8000/M9000 Servers Product Notes* at:
`http://www.fujitsu.com/sparcenterprise/manual/notes/`

Adobe Reader can be downloaded from the following website for free:
`http://www.adobe.com/products/acrobat/readstep2.html`

SPARC Enterprise M8000/M9000 Servers Documention

System planning and installation preparation

- SPARC Enterprise M8000/M9000 Servers Overview Guide
- SPARC Enterprise M8000/M9000 Servers Site Planning Guide
- SPARC Enterprise Equipment Rack Mounting Guide

System installation and component addition/ removal

Manuals related to the SPARC Enterprise M8000/M9000 servers installation:

- SPARC Enterprise M8000/M9000 Servers Getting Started Guide
- SPARC Enterprise M8000/M9000 Servers Unpacking Guide
- SPARC Enterprise M8000/M9000 Servers Installation Guide
- SPARC Enterprise M8000/M9000 Servers Safety and Compliance Guide
- SPARC Enterprise M4000/M5000/M8000/M9000 Servers Administration Guide
- SPARC Enterprise M4000/M5000/M8000/M9000 Servers XSCF User's Guide

Manuals related to SPARC Enterprise M8000/M9000 servers expansion (active, cold, and hot expansion):

- SPARC Enterprise M8000/M9000 Servers Service Manual

Operation and management

- SPARC Enterprise M4000/M5000/M8000/M9000 Servers Administration Guide
- SPARC Enterprise M4000/M5000/M8000/M9000 Servers XSCF User's Guide
- SPARC Enterprise M4000/M5000/M8000/M9000 Servers XSCF Reference Manual
- SPARC Enterprise M4000/M5000/M8000/M9000 Servers XSCF Control Package (XCP) Release Notes
- SPARC Enterprise M4000/M5000/M8000/M9000 Servers Dynamic Reconfiguration (DR) User's Guide

---

Repair and troubleshooting

- SPARC Enterprise M8000/M9000 Servers Service Manual
- SPARC Enterprise M4000/M5000/M8000/M9000 Servers Administration Guide

---

Globalization

- For SPARC Enterprise M8000/M9000 servers, the documents of English, French, Japanese, Korean, Simplified Chinese, and Traditional Chinese versions will be offered on the website: `http://www.fujitsu.com/sparcenterprise/manual/`

Installation Steps for SPARC Enterprise M8000/M9000 Servers

Step 1	• Check the power source, air conditioning equipment, and location of the installation site. For details, see the *SPARC Enterprise M8000/M9000 Servers Site Planning Guide*.
Step 2	• Unpack the product package by referencing the *SPARC Enterprise M8000/M9000 Servers Unpacking Guide*, which comes with the server.
Step 3	• Install the main unit. If there is an expansion cabinet to be connected to the SPARC Enterprise M9000 or a power supply cabinet to be mounted in the SPARC Enterprise M8000 or SPARC Enterprise M9000, connect each of them to the relevant cabinet. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 4	• Connect the input power cables to the main unit. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 5	• Connect the console to the main unit. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 6	• Turn on the main line switch of the main unit. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 7	• Set necessary information for hardware. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 8	• Turn on the power to the main unit. POST is automatically executed after power-on. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 9	• Set a LAN port on the XSCF unit and connect it. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide* and the *SPARC Enterprise M4000/M5000/M8000/M9000 Servers XSCF User's Guide*.
Step 10	• If you are installing other peripheral devices in the main unit, proceed to Step 11. • If you are not installing peripheral devices in the main unit, proceed to Step 14.
Step 11	• Turn off the power to the main unit. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 12	• Install other peripheral devices. For details, see manuals supplied with each peripheral device.
Step 13	• Turn on the power to the main unit. POST is automatically executed after power-on. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 14	• Check the network connection of domain. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide*.
Step 15	• Confirm the operation by using SunVTS. For details, see the *SPARC Enterprise M8000/M9000 Servers Installation Guide* and the SunVTS User's Guide.
Step 16	• Perform the setup required for the operation of the system. For details, see the *SPARC Enterprise M4000/M5000/M8000/M9000 Servers Administration Guide*. Notes: We recommend you to install Enhanced System Facility (ESF) and apply PTF for safe operation of the system. See the following website for details. `http://www.fujitsu.com/sparcenterprise/manual`

Accessing Important Information for SPARC Enterprise Series Servers

Before you deploy your server, check for the Product Notes for your server and other important information on the following websites.

Global Site

`http://www.fujitsu.com/sparcenterprise/manual/notes/`

North American Site

`https://download.computers.us.fujitsu.com/`

Japanese Site

`http://primeserver.fujitsu.com/sparcenterprise/manual/notes/`

Accessing Documentation

The following websites provide the latest versions of SPARC Enterprise Series manuals:

Global Site

`http://www.fujitsu.com/sparcenterprise/manual/`

North American Site

`https://download.computers.us.fujitsu.com/`

Japanese Site

`http://primeserver.fujitsu.com/sparcenterprise/manual/`

Reader's Comments Regarding This Manual

If you have any comments or requests regarding this manual, or if you find any unclear statements in the manual, please state your points specifically, and forward it to the system engineer (SE) in charge, or your sales representative.

FUJITSU LIMITED, 1-1, Kamikodanaka 4-chome, Nakahara-ku, Kawasaki-shi,Kanagawa-ken 211-8588, Japan.

Sun Microsystems, Inc., provided technical input and review on portions of this material. This distribution may include materials developed by third parties. Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Fujitsu and the Fujitsu logo are registered trademarks of Fujitsu Limited.

Sun, Sun Microsystems, the Sun logo, Java, Netra, Solaris, Sun Ray, Answerbook2, docs.sun.com, OpenBoot, and Sun Fire are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon architecture developed by Sun Microsystems, Inc. SPARC64 is a trademark of SPARC International, Inc., used under license by Fujitsu Microelectronics, Inc. and Fujitsu Limited. The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

FUJITSU LIMITED

Manual Code C120-E323-03EN
Part No. 819-7880-10
April 2007, Revision A